



Origin	al Operating Manual	elektronik by
Photoelectric proxi	mity switch type IRI	D-010-XB2-OP
0158 IECEx BVS 14.0108X		
	ATEX and IECEx certification	
(2x)	• For use in Ex Zones (0),1, 2, (20), 21, 22	
IL 2(1)G IECEx marking:	Also for using with certificated fibre optics	
II 2(1)D Ex db [op is Ga] IIC T Ex db [op is Ga] IIC T Ex th [op is Da] IIIB T	• Robust sensor for	industrial applications
Technical data	IRD-010	I-XB2-OP
Optical range	1m. adiu	stable
Type of Ex protection Gas, directive 2014/34/EU	II 2(1)G Ex db [op is Ga] IIC T6 Gb	
Type of Ex protection Dust, directive 2014/34/EU	II 2(1)D Ex tb [op is Da] IIIB T100°C Db IP67	
For use in Ex Zones	Zones (0), 1,2, (20), 21, 22	
Maximum optical radiant power	<=15mW	
Maximum optical radiant intensity	<=5mW/mm ²	
Light source	Infrared 870nm	
Response time	5ms	
Power-up delay time	500ms	
Supply voltage	24 VDC +-10%	
Absolute maximum supply voltage Um	30VDC	
Current consumption	61mA	
Maximum power dissipation	1.61W	
Utilization category, EN 60047 5 1	PNP type, 100mA, short-circuit protected	
Housing	M30 brass nickel plated	
Enclosure rating, EN 60529	IP67	
Ambient working temperature range Tamb	-20°C up to +60°C	
Storage temperature range	-30°C +70°C	
Relative humidity	15% 80%, non-condensing	
Vibration and shock resistance	Vibration: 30g over 20Hz to 2kHz. Shock: 100g for 3ms	
Pollution degree, EN 60664-1:2007	4	A D 1
Connection cable	3 + PE x 0.5mm ² TPU s	hielded halogen free
	leads numbering marked, for	drag chaining, length; 3m
Accessories	-2x nuts M30 (or optional 1 clamp	o)
	-1x Spare safety screw with pack	king ring for potentiometer sealing
Options	- Cable length:	Jp to 100m, on request
	- Integrated time functions:	Rise or fall time delays, on request
	- Type IRD-010-XB2-OP-5226.	
Function and LED indication	Light barrier	
	Beam free	Beam interrupted
	Proximity switch	Proximity switch
	Proximity switch	Proximity switch
	with fibre optic	with fibre optic
	Light detected, LED = Yellow or green	No light detected, LED = Red
Wiring:	0.1.1241/PC	
1 = +24 VDC		
2 = 0V		
3 = Output	$R_{15\Omega}$	$R15\Omega$
white = Cable shield		
	0 2 0V	0 2 0V
Wiring for inverted output function:		0 2 +24VDC
1 = 0V		
2 = +24 V D C		
vellow-green = PF		- 3 Output
white = Cable shield	│○ 1 0V	0 1 OV
Ex related designation of the devices		Monufactures with address
EX TEIRLEU DESIGNATION OF THE DEVICES	0-XB2-OP(-S226) [.] II 2(1)G Ev.db	Ivianuracturer with address
	(I) (() () () () () () () () (op is Da] IIIB T100°C Db IP67
ATEX EC-typ IFCFx Certif	be Certification No: BVS 10 AT No: IFCFx 14 (EX E130 X DEKRA
Tamb: -20	°C up to +60°C Electrical data	according to the chart
Date of prod (X designation of the certification number: Fibre optics mu	use only be applicated with sensors with certifi	cated limited optical power)
	,,	



Operating Manual, EC-/EU - Declaration of Conformity:

Mounting prescriptions **Ex Protection:**

It is necessary to take into consideration the valid international and national rules and regulations (EN 60079-14). The maximum input voltage Um=30VDC must not be exceeded. The local equipotential bonding have to be done. The protective earth (PE) is solid connected with the housing. The cable have to be installed and protected against damages. The cable with termination fittings. or in cable tray systems and installed in a manner to avoid tensile stress at the termination fittings. To connect cables inside hazardous locations only use certificated Exe housings. All cable terminals must be connected outside hazardous locations. Additional optical lenses are not allowed in hazardous locations. In dust Ex zones, do not operate the sensors without fixed dustproof sealing crew. After adjust the potentiometer, the dustproof sealing crew with undamaged packing ring, must be screwed down. Damaged or lost screws or packing rings must be replaced. Type IRD-010-XB2-OP(-S226): Only for use in Exzones 1, 2, 21, 22. The limited optical radiation can operate into hazardous locations 0 or 20 over certificated fibre optics or through a viewing glass.

General mounting prescriptions:

Do not exceed the maximum ratings. The electrical connections must be exactly as shown in the connection diagram. The cable shield must be connected short. The cable shield should be connected to the protection earth, large-surfaced. Connection cables must not be installed parallel to high voltage cables. Do not exceed the maximum ratings.

Function

The sensor works basically as proximity switch on diffuse optical reflections. If the sensor detects reflected light, the output of in accordance with local waste disposal regulations. switches to +24VDC. If the sensor works under safe conditions the LED shows green. If the sensor detects only poor reflected light, the LED shows yellow. If no reflected light will be recognized, the output switches OFF and the LED shows red. The load must be connected to 0V(-).

Function at inversely connection of the supply voltage The sensor works basically as proximity switch on diffuse optical reflections. If the sensor detects reflected light, the output switches OFF. If the sensor works under safe conditions the LED shows green. If the sensor detects only poor reflected light, the LED shows yellow. If no reflected light will be recognized, the output switches to +24VDC and the LED shows red. The load must be connected to 0V(-).

Range

s5,2017-09-

-IECEX

-do

-010-XB2-

IRD-

The nominal optical range is specified on white paper A4, 80. The range will be influenced by the color, kind of surface and shape of the object.

For efficiently detection solutions look for our multiple program of certificated fibre optics, also for high temperature areas.

Maintenance

Fibre optics

Protect the sensor and the optional fibre optics against pollution. If the fibre optics or the sensor lenses are contaminated, clean with alcohol. Do not use aggressive solvents. Optical fibres can be destroyed by strong solvents. Equipment must only be repaired or serviced by the manufacturer.

General safety instructions

The sensors must not be used for fails-safe applications! In worst case the output can change to any state! Do not turn much too often the potentiometer axis! When installing and operating with the sensor, it is necessary to take into consideration the relevant international and other national regulations:

EN 60079-14, single directive 1999/92/EC.

The sensors are conform to the following directives and standards:

IEC/EN60079-0:2012+A11:2013, IEC/EN60079-1:2014, IEC/EN 60079-28:2015, IEC/EN60079-31:2014, EN60529:2014, EN60950-1:2006; EN 61000-4-2 to EN 61000-4-6, EN 61000-6-1/-2, EN 61000-6-4. ATEX directive: 2014/34/EU. Machine directive: 2006/ 42/EC, EMC directive: 2014/30/EU, RoHS directive: 2011/65/EU.

General Notes, disposal

We reserve the right to modify our equipment. Our equipment is designed such way, that it has the least possible adverse effect on the environment. It neither emit or contain any damaging or siliconized substances and use a minimum of energy and resources. No longer usable or irreparable units must be disposed

EC-/EU-Declaration of conformity

Matrix Elektronik AG (Manufacturer) Kirchweg 24 CH-5420 Ehrendingen Tel.:+41 56 20400-20 IECEx certification: Exd [op is Ga] IIC T6 Gb, Extb [op is Da] IIIB T100°C Db IP67. Certification No. IECEx BVS 14.0108X.

http://jecex.jec.ch/jecex/jecexweb.nsf/0/EE79714C0BAEE6E5C1257D7E0044E6A9?opendocumer ATEX certification: II 2(1)G Ex db [op is Ga] IIC T6 Gb, II 2(1)D Ex tb [op is Da] IIIB T100°C Db IP67. Certification No. BVS 10 ATEXE 130 X, DEKRA EXAM GmbH, Zertifizierungsstelle, Carl-Beyling-Haus, Dinendahlstrasse 9, D-44809 Bochum, Ident number: 0158. ATEX certification of quality type production of Ex devices according to the ATEX directive 2014/34/EU, CE 0158. Certification No: BVS15ATEXZQS/E118. The conformity of the devices with the EC standards and directives and the EC-type examination certificate and the observation of the Quality Safety System ISO 9001:2008 with the ATEX module "Production", declares:



Hans Bracher, Matrix Elektronik AG

info@matrix-elektronik.com