5 Simplex

UL, ULC, CSFM Listed; FM Approved*



4100ES Fire Control Panels

InfoAlarm Command Center for Fire Alarm Control Panels with EPS+ Power Supplies

Features

Multi-line expanded content display interface for Simplex® 4100ES Series fire alarm control panels, available with the following products:

- Fire alarm control panels (stand-alone or networked)
- Network Display Units (NDU) supporting up to 12,000 points
- Remote InfoAlarm Command Centers mounted in a dedicated cabinet (4100ES control panels support Remote InfoAlarm Command Centers independent of host panel display type)
- Models include Enhanced Power Supply (EPS+) and battery charger (9 A total) with on-board *IDNAC* SLCs (signaling line circuit) for addressable appliance control, *IDNet 1*+ isolated addressable device control channel, and programmable function auxiliary output
- For additional information concerning EPS+ power supplies and their enhanced features, refer to 4100ES data sheet S4100-0100
- For additional 4100ES related applications, including models with power supplies for conventional non-addressable NACS, refer to data sheet S4100-0045

InfoAlarm Command Centers provide customized operating convenience:

- "Activity in System" primary display choices include:
 First and Most Recent, First 5 and Most Recent, First 8,
 Site Plan with activity status icons, General Alarm, or
 Direct to List; selectable individually by event type
- System reports are easily viewed; logs can be read with minimal scrolling required
- Up to six "softkeys" per screen provide functions that vary with the particular screen information aiding operators to determine how to proceed
- Up to two languages are available per system, easily selected by programmable key press (systems with IMS/GCC/NPU or 2 x 40 LCD panels or annunciators require one language to be the default font)
- International models allow customized language legends for operator keys and status LEDs

Display properties:

- 320 x 240 dot matrix (QVGA) display provides an active area of 4.53" W x 3.4" H (115 mm x 86 mm) displaying up to 854 characters using standard ASCII character font
- Bright white LED backlighting provides efficient and long lasting illumination; operation is selectable as continuous or off with power fail or with no key presses

UL listed to Standard 864

Introduction

Displaying more information. 4100ES Controls using the InfoAlarm Command Center provide an expanded content, multi-line LCD interface that requires minimal key presses to access detailed information. Because it is system-powered, its detailed information is provided without requiring separate supplementary equipment.



InfoAlarm Command Center for Control Panel Mounting



InfoAlarm Command Center in Remote Cabinet

Introduction (Continued)

InfoAlarm Command Center Control Panel. By using a larger area format instead of an individual text line display, the LCD provides text information for Alarm, Supervisory, or Trouble. The format is flexible and able to be customized per application allowing additional information to be presented to suit the specific application.

Description

InfoAlarm Command Centers for 4100ES fire alarm systems provide a large display with extended information content, dual language support including 2 byte character languages, and an intuitive control key interface per the following:

- Up to 10 InfoAlarm Command Centers are supported per 4100ES control panel; able to allow one InfoAlarm Command Center to take-control and to designate access levels for interfaces not in-control; LEDs can be programmed for in-control status indications
- Menu-driven format conveniently prompts operators for the next action required
- Key controls are provided to select the highlighted entry, load next screen of information, or jump to top or bottom of activity lists

(continued next page)

^{*} This product has been approved by the California State Fire Marshal (CSFM) pursuant to Section 13144.1 of the California Health and Safety Code. See CSFM Listing 7165-0026:0251 for allowable values and/or conditions concerning material presented in this document. It is subject to re-examination, revision, and possible cancellation. Additional listings may be applicable; contact your local Simplex product supplier for the latest status. Listings and approvals under Simplex Time Recorder Co. are the property of Tyco Fire Protection Products.

Description (Continued)

- Direct point callup displays individual points alphabetically and then homes in on the logical choice as more point information is entered
- A Site Plan bitmap can be displayed for reference; icons can be added to indicate system status
- Up to 50 custom point detail messages can be generated
- Date formats are either MM/DD/YY or DD/MM/YY
- Time formats are either 24 hour or 12 hour with AM/PM
- System Normal screen supports a gray scale bitmap (watermark) for location name, company logo, or site plan

Control Panel Operation Reference

THREE PROGRAMMABLE

selectable as red or green

designating a Ground Fault

ULC SYSTEMS require

indicator

LEDs provide custom labeling,

the top two LEDs are selectable

as red or yellow, the third LED is

Custom label insert (typical

choices shown for reference)

320 x 240 DOT MATRIX DISPLAY, White LED backlighting provides easy viewing; operation is programmable for key inactivity timeout and/or AC power fail

PRIMARY "ACTIVITY IN SYSTEM"

DISPLAY OPTIONS: Choices include "First 8" (shown below for "Fire Alarm in System"), "First and Most Recent," "First 5 and Most Recent," "Site Plan," "General Alarm," or "Direct to List." After the event is acknowledged, screen reverts to the sequential event list until Clr/Exit softkey is selected or after timeout (~ 30 seconds); applicable to Fire Alarm, Priority 2 Alarm, System Supervisory, and System Trouble, each category is independently selectable for primary display mode


SIX SOFT KEYS are available when required. This sample provides Menu to call up the available operations; More Info to call up specific point details, Site to call up the Site Plan Graphic Screen, Event Time (while pressed) displays time and date for all displayed events, and CIr/Exit; the following are other typical soft keys:

Point Enable and Disable Force On or Arm Force Off or Disarm Return On/Off or Arm/Disarm to Auto Mode Event Time Request More Information Request

NUMERIC KEYPAD for

point category and point selection (alphabet characters are not used at this time)

C/Exit Key duplicates the CIr/Exit softkey when present



SEVEN PROGRAMMABLE FUNCTION SWITCHES, each equipped with dual color LED indicators; the top six LEDs are selectable as either red or yellow, the bottom LED is selectable as either red or green; NOTE: Program the bottom switch as "Lamp Test" for UL listed systems

FIRE ALARM ACK acknowledges a Fire Alarm condition, logs the acknowledge, silences the operator panel and all annunciator tonealerts, and displays sequential alarm list

PRIORITY 2 ACK acknowledges a Priority 2 Alarm condition, logs the acknowledge, silences the operator panel and all annunciator tonealerts, and displays sequential Priority 2 alarm list

SUPV ACK acknowledges system supervisory conditions, logs the acknowledge, silences the operator panel and all annunciator tonealerts, and displays sequential supervisory condition list

TROUBLE ACK acknowledges system troubles, logs the acknowledge, silences the operator panel and all annunciator tonealerts, and displays sequential trouble list

ALARM SILENCE causes notification appliances to be deactivated, typically after evacuation is complete and while alarm source is being investigated. May be programmed to silence audible notification and allow visible notification to continue (strobes still flashing).

SYSTEM RESET restores control panel to normal when all alarmed inputs are returned to normal

2


SIX SYSTEM STATUS INDICATOR

LEDs provide system status indications in addition to LCD information, LEDs flash to indicate the condition and then when acknowledged, remain on until reset: Fire Alarm & Priority 2 Alarm, red LED Supervisory & Trouble, yellow LED Alarm Silenced, yellow LED AC Power, green LED (on for normal)

FIRST OCCURRENCES (UP TO 5) AND MOST RECENT OCCURRENCE,

ACTIVITY IN SYSTEM DISPLAY ("Fire Alarm in System" screen shown for reference, see page 2 for a First 8 Events display)

FIRST OCCURRENCE advises of the time, date, device type, and custom label of the first occurrence of the event type displayed; the numerical count identifies the sequence of occurrence; when selected as the primary display screen, display of first occurrence and most recent occurrence is maintained until events are acknowledged which brings up the event list (similar to the First 8 display); the display reverts back to "First and Most Recent" when the Clr/Exit softkey is selected or after a time delay




MOST RECENT advises of the time, date, device type, and custom label of the most recent occurrence of the list shown, in this case, the Fire Alarm list


Site Plan with Event Icons

Site Plan Bitmap. The InfoAlarm Command Center supports a site plan monochrome bitmap image (size is 281 pixels wide by 192 pixels high) that can also display icons indicating activity and location. Shown to the right is a sample site plan with icons shown in each building area. For this example, each area is showing an "A" for an initiating device in alarm, a "WF" for waterflow occurring, and an icon indicating notification appliances in alarm. (Icons can be created for site specific symbology, these are for example only.)

Site Plan Selection and Detail. If desired, the site plan can be the primary display screen for system activity or can be for reference, available by selecting the "Site" softkey. Depending on the facility layout, the site plan can also be a convenient location for common reference information such as primary call phone numbers, street address, etc. to assist operators in their assigned response.

System Normal Screen. The site plan (or another bitmap image) can be displayed on the System Normal screen as a grey image watermark behind the screen text. (Size and type are the same as that for a site plan bitmap). This can be used to identify the specific location of the 4100ES or can display a site-specific logo or other information. (A sample is shown on page 6.)






Customized Emphasis

The Main Menu screen illustration to the left demonstrates how print/display statements appear for status information or for prompting of user input. Other examples of this format occur when setting time and date, entering a password, or identification of a status change such as point enabling or disabling. Use of this feature allows the display to clearly focus the user on required information or actions.

Information Review


The Trouble Log History screen shown to the right identifies the ability to view multiple event entries with minimal scrolling. For specific information access, pressing "Next" or "Previous" on the keypad highlights the selected next or previous item in the list as indicated by the arrow and the bolded first line of Entry 6.

For access to the next or previous full screen of information, use the Page Dn or Page Up keys located to the right of the soft keys, each to the right of the display.



Additional Primary Display Screens

Below are samples of a First and Most Recent primary display and of a General Alarm display.




First and Most Recent Primary Display Option



General Alarm Primary Display Option

International Display Details



Additional 4100ES Data Sheet Reference

Data Sheet	Subject		Data Sheet	Subject	Data Sheet	Subject
S4100-0100	4100ES Panel Reference	With EPS	S4100-0034	Audio/Phone Modules		Additional InfoAlarm Command Center Model Reference
S4100-0102	Network Display Unit	power	S4100-0032	LED/Switch Modules		
S4100-0103	MINIPLEX Transponders	supplies	S4100-0037	Enclosure Options		
S4100-0038	Remote Annunciators		S4100-0031	Additional 4100ES Basic Panel Reference		

5

4100ES Master Controller with InfoAlarm Command Center*

Model	Model Type	UL	ULC	Voltage	InfoAlarm Command Center Type	Master Controller Features
4100-9314	English	\	_			
4100-9315	English		,			9 A system power supply/battery charger (EPS+), 250 point IDNet 1+ interface, 3 IDNACs, auxiliary relay, and external RUI+ communications interface
4100-9316	French		•			
4100-9513	International	\	_	120 VAC, 50/60 Hz	Master Controller Assembly; flat keys with inserts for custom key labels	
4100-9512	International	1	_	220/240 VAC, 50/60 Hz		

Network Display Unit (NDU) with Voice, Master Controller with InfoAlarm Command Center (NOTE: See data sheet S4100-0102 for NDU feature details)

Model	Model Type	UL	ULC	Voltage	Description
4100-9352	English	\	_	120 VAC,	Top Bay Equipment: InfoAlarm Command Center (raised keys with fixed labels), 9 A System Power Supply (SPS) with RUI, Standard CPU module, Network Interface Module (select media cards separately), and 4100-0640 InfoAlarm Memory Expansion (NOTE: SPS IDNet channel and NACs are
4100-9355	English	_	1	50/60 Hz	disabled) Second Bay Equipment: Voice Command Center (VCC) Bay with Standard CPU Module, Network Interface Module (select media cards separately), 9 A EPS+ with 250 Point IDNet 1+ Interface, (3) 3 A IDNACs, and RUI+ output

InfoAlarm Command Center Memory Option (may be required to be ordered separately, see description details)

Model	Description
4100-0640	Display Memory Expansion Module; included with NDU systems; required for all InfoAlarm Command Centers connected to a panel if any are using 2 byte character fonts; 6 Meg module mounts on rear of display board

Remote InfoAlarm Command Center Control Assembly with Cabinet for Surface Mounting


Model	Cabinet Color	Application Type	Listing	Description
4100-9401	Red	En all'ab	UL & ULC	Remote InfoAlarm Command Center with cabinet; for surface mounting; includes mounting box and door assembly with glass insert; uses RUI communications; requires external 24 VDC system voltage; see illustrations on page 7 and Installation Instructions 579-687 for details
4100-9403	Platinum	English		
4100-9421	Red	French/Canada	ULC	
4100-9423	Platinum	Frencii/Canada		
4100-9441	Red	International	UL	
4100-9443	Platinum	International		

^{*} Please refer to data sheet S4100-0101 for detailed descriptions of the 4100ES with EPS+ Basic Control Panel details, standard product features, options, and reference for related fire alarm control panel products, see data sheet list on page 5 for additional reference.

6



Remote InfoAlarm Command Center Mounting Reference



7

Specifications

General Display Specification	ations			
	Dot Matrix Size	320 x 240		
	Active Display		ader, footer, and softkey	
Size Reference	Area			
	Characters	Up to 854 characters total using standard ASCII character font		
	Designation	QVGA; one quarter of standard VGA (Video Grap	hics Array) display	
Display Polarizer Type		Transflective with rear backlight		
Display Adjustment		Contrast adjustment is located on the controller module		
Backlight		White LEDs with intensity adjustment and selectable AC power fail operation; intensity adjustment is located on the controller module		
Backlighting Operation Option	s	On continuously; Off with AC power fail until a switch is pushed; selectable timeout without switch activity		
Control Panel Mounted Ir	foAlarm Command	Center Current Requirements		
Master Controllers (4100-931 4100-9315, 4100-9316, 4100-95		417 mA @ 24 VDC	With 200 IDNet devices	
4100-9512) Network Display Units, Voic (4100-9352, 4100-9355)	e Alarm	770 mA @ 24 VDC; backlight and tone-alert on	and 20 device LEDs in alarm	
Remote Annunciators wi	th InfoAlarm Comma	and Center, Powered from Control Panel		
Voltage		19 to 33 VDC (24 VDC nominal), system supplied; requires separate wiring		
	Supervisory	169 mA @ 24 VDC		
Current	Alarm			
Mounting Details; Stand-Alone	Cabinet Models	See page 6 for reference illustration		
	Туре	RUI (Remote Unit Interface) external annunciator (signaling line circuit); RUI+ provides isolated out		
4100ES Capacity,	Capacity	Up to 31 total remote RUI devices, including up to 10 InfoAlarm Command Center devices		
RUI and RUI+ Output Referen	RUI Device Reference List	1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -		
	Data	Single twisted, shielded pair, 18 AWG (0.82 mm²)		
	Power			
Wiring Requirements Earth		A dedicated earth ground connection to the electrical box is required for proper ESD and EMI protection; wire in accordance with NFPA 70 (National Electrical Code) Article 250		
Custom Point Detail Mes	sages			
Message Location Details		Select "more info" softkey when investigating point detail and scroll to the bottom of the information; typical messages might include contact details (phone numbers, pager numbers, etc.) and other contact or reference information		
Number of Messages		Up to 50		
· ·	Character Details	120 characters; visible characters = 116; (lines 1 and 2 require one carriage return character and one line feed character)		
Message Size	Line Details	3 lines total; 40 characters maximum per line; line 3 may be limited to 36 visible characters depending on characters in lines 1 and 2		
Fundament - I	Operating Temperature	32° to 120°F (0° to 49° C)		
Environmental —	Operating Humidity			

TYCO, SIMPLEX, and the product names listed in this material are marks and/or registered marks. Unauthorized use is strictly prohibited. National Electrical Code and NFPA are trademarks of the National Fire Protection Association.

